

ART. NO 818014


## Instructions

### 14PCS Radiator pressure test set



#### OPERATING INSTRUCTION

1. Remove the lid of radiator. If the radiator is in high temperature, wait for it to cold down or cover with a wet towel until it reaches normal temperature.
2. Select the correct test adapter.
3. Attach the correct test adapter, then screw on the radiator.
4. Press the hand pump to inflate the pressure up to 15-20psi.  
**Caution:** Do not exceed the max. pressure of gauge.
5. Check the pressure gauge. If the pointer is down, you must inspect the lines of radiator, then repair or replace the damaged parts.
6. After servicing press the release button to release the pressure of radiator until the pressure gauge to zero.
7. Before storing
  - 7-1. Attach the test adaptor to the quick coupler of hand pressure pump, then press the hand pressure pump few times to push remnant water out of the test adaptor.
  - 7-2. Drop pneumatic oil into the air hose of the hand pump end to lubricate the piston of hand pump.
8. Be careful to use this tools and clean them.



#### APPLICATION LIST

0. Temperature gauge
1. Pressure testing pump with gauge
2. Large trucks, GM (Cadillac)
3. Mercedes Benz, Ford, Large truck, Japan vehicle 123 series, GM (Buick), Jeep
4. Peugeot, Japan vehicle 124 series (Mitsubishi, Nissan, Mazda, Toyota, Subaru, Infiniti, GEO, Suzuki, Isuzu, Lexus)
5. Japan vehicle 125 series (Honda, Toyota, Suzuki, Mitsubishi)
6. Mercedes Benz (ML Class), GM (Achieva, Skylark, Grand AM:1992-2002)
7. Volvo, SAAB Saudi, Citroën, Renault, Fiat, Peugeot, Alfa Romeo, Jeep
8. New Volkswagen
9. New Audi (A4, A5, A6), BMW 345, Volkswagen T4
10. BMW
11. Audi, Volkswagen
12. Ford, International, GM, Rover
13. Mercedes Benz

